


SERVICE VALVES



COMPRESSOR MODEL	SUCTION SERVICE VALVE RCD P/N	DISCHARGE SERVICE VALVE RCD P/N
------------------	-------------------------------	---------------------------------

5F COMPRESSORS

5F20-S674	06DA660063	06DA660062
5F20-A684	06DA660063	06DA660062
5F20-S684	06DA660063	06DA660062
5F30-A189	06EA660090	06DA660065
5F30-S644	06EA660090	06DA660065
5F30-A219	06EA660090	06DA660065
5F30-S664	06EA660090	06DA660065
5F40-A219	06EA660090	06DA660065
5F40-S219	06EA660090	06DA660065
5F60-A219	5F660-002	5F660-001
5F60-S219	5F660-002	5F660-001

5H COMPRESSORS

5H40-(+)219	5H660-008	5F660-002
5H46-(+)219	5H660-008	5F660-002
5H60-(+)219‡	06LA660010	06LA660010
5H66-(+)219‡	06LA660010	06LA660010
5H80-(+)219	06LA660010*	06LA660010◀
5H86-(+)219	06LA660010*	06LA660010◀
5H120-(+)219‡	06LA660011	06LA660011
5H126-(+)219‡	06LA660011	06LA660011

(+) May be either "A" (Remanufactured) or "S" (New Manufactured)

‡ These Models require a suction and a discharge manifold in order to mount the service valve.

* Requires a suction valve adapter (P/N: 5H660-006).

◀ Requires a discharge valve adapter (P/N: 5H660-005).